



EBS & MAED

Hands-on 8: Inputting Data to MAED-EL

Learning outcomes

By the end of this exercise you will be able to:

- 1) Input electricity system assumptions into MAED-EL
- 2) Input calendar information into MAED-EL
- 3) Input modulating coefficients into MAED-EL
- 4) View MAED-EL calculation results in several formats

Activity 1: General Information

As in the module MAED-D, the first window displayed once the MAED-EL module is selected, is the window for handling the cases. When you open this window for the first time, you should see a case called "Demo MAEDEL." Click on this case to open it.



MAED Model for Analysis of Energy Demand

En Es Fr

Manage case studies

MAED D
MAED EL

Model for Analysis of Energy Demand

Planning and Economic Studies Section
Division of Nuclear Power
Department of Nuclear Energy
International Atomic Energy Agency

MAED Model for Analysis of Energy Demand

En Es Fr

Manage case studies

MAED EL CASE STUDIES

Demo MAEDEL 18-01-2021 11:53:47

Actions
Manage case studies

Create new case study

Name of the case study


Case description

Create case study

Restore case study

+ Select case... Restore

The information in MAED-EL is organized into four groups: general information provided by the user, the coefficients provided by the user, calculate, and the results of the model. You can navigate between this information using the menu on the left side of the screen.



General data
Name of the case study **Demo MAEDEL**

Definitions (name, years, description)

Name of the case study: Demo MAEDEL
Case description:
Years: 2038

Sectors & Clients

Sectors	Coefficient of the base year	Add new client	Clients
Industry1	<input checked="" type="checkbox"/>	<input data-bbox="889 909 911 936" type="button" value="+"/>	Ind1 <input data-bbox="1344 909 1365 936" type="button" value="X"/>
Transport	<input type="checkbox"/>	<input data-bbox="889 978 911 1005" type="button" value="+"/>	Tm1 <input data-bbox="1344 978 1365 1005" type="button" value="X"/>
Household	<input type="checkbox"/>	<input data-bbox="889 1047 911 1075" type="button" value="+"/>	Hou1 <input data-bbox="1344 1047 1365 1075" type="button" value="X"/>
Service	<input type="checkbox"/>	<input data-bbox="889 1117 911 1144" type="button" value="+"/>	Serv1 <input data-bbox="1344 1117 1365 1144" type="button" value="X"/>


The input data that the user must provide are:

- The general information of the case
- The sectors to be evaluated
- Clients within each sector
- The annual electricity demand by sectors and how much of it is supplied by the network
- The structure of the electricity demand by clients
- Transmission and distribution losses
- Time divisions of the year
- The modulating coefficients of the load curve for each of the clients.

We will start at the top of the navigation menu on the left to fill in this information.

Start on the “General data” page under the “General information” tab. First go to the top box with the heading “Definitions (name, years, description)”. The first information that the user must provide is the years of the study period, which must be input consecutively and separated

by commas. The first year is the base year of the study. It is good to recall that each time interval must be equal to or greater than the interval preceding it. In this demo case, the only year considered is 2038. To save the information in each box and go to the next step, use the Save Data button, which is the green floppy disc icon on the top right of every box. You can also edit the name of the case study and case description in this box.



General data

Name of the case study **Demo MAEDEL**

Definitions (name, years, description)

Name of the case study: Demo MAEDEL

Case description:


Years: 2038

Sectors & Clients

Sectors	Coefficient of the base year	Add new client	Clients
Industry1	<input checked="" type="checkbox"/>	+	Ind1
Transport	<input type="checkbox"/>	+	Trn1
Household	<input type="checkbox"/>	+	Hou1
Service	<input type="checkbox"/>	+	Serv1


On the same page, the next box is “Sectors & Clients”. This demo case already has 4 sectors with 1 client each, but you can use the green plus icon at the top of the box to add a new sector. You can also edit the name of each sector and check the box to see if the modulating coefficients of the base year should be used to calculate the hourly demand in the other years of the study.

Clients are defined for each sector. The green plus to the right of each sector allows you to add new clients, and the editable list of clients appears to the right of the add button. By default all sectors must have at least one client to represent it, so the delete option is not available for the first client in each sector. The red X on the right of each sector allows you to delete that client or sector.



Next, click on “Electricity” page under the “General information” tab on the navigation menu on the left. Starting on the “Annual electricity demand” tab on the top of the page, you can input the annual electricity demand for each sector for each year in the model, and the programme calculates the total demand per year.

The buttons on the top right of the box allow you to chart the data with the “chart” cell checked, increase or decrease the number of decimal places, download the data to excel, save the data, and open a window with more information about the data to be input in this box.



MAED Model for Analysis of Energy Demand

Electricity

Name of the case study: Demo MAEDEL

Annual electricity demand | Electricity supplied from the grid | Electricity demand per client | Transmission and distribution losses

Annual electricity demand


Item	Unit	2038	Chart
Industry1	GWh	10000.000...	<input checked="" type="checkbox"/>
Transport	GWh	10000.000...	<input checked="" type="checkbox"/>
Household	GWh	10000.000...	<input checked="" type="checkbox"/>
Service	GWh	10000.000...	<input checked="" type="checkbox"/>
Total	GWh	40000.00...	<input checked="" type="checkbox"/>

Data notes

©2020, Version: 2.0.0.20201120

Next, click on the “Electricity supplied from the grid” tab at the top of the page. This box is where you can define how much of the total electricity demand must be supplied by the main grid. Because MAED calculates the hourly electricity demand to be supplied by the grid, isolated or self-production systems are not included in the model.

We must define how much of the electricity demand must be satisfied by the main grid for each of the sectors for each model year. The values are entered in percentage, where 100% means that all the demand of the sector must be met by the grid.



MAED Model for Analysis of Energy Demand

Electricity

Name of the case study: Demo MAEDEL

Annual electricity demand: Electricity supplied from the grid

Electricity demand per client

Transmission and distribution losses


Electricity supplied from the grid

Item	Unit	2038	Chart
Industry1	%	100.00000	<input checked="" type="checkbox"/>
Transport	%	100.00000	<input checked="" type="checkbox"/>
Household	%	100.00000	<input checked="" type="checkbox"/>
Service	%	100.00000	<input checked="" type="checkbox"/>

Data notes

©2020, Version: 2.0.0.20201120

Now click on the “Electricity demand per client” tab at the top of the page. You can define the share of sector demand from each client in this box. If the sector has a single client the value is equal to 100%. The model calculates the total to verify that the defined values add up 100%, otherwise it will point to it as an error.



MAED Model for Analysis of Energy Demand

MAED EL About

En Es Fr

Manage case studies

General information

General data

Electricity

Calendar

Coefficients

Industry1 (1)

Transport (1)

Household (1)

Service (1)

Calculate

Results

Electricity

Name of the case study Demo MAEDEL

Annual electricity demand Electricity supplied from the grid Electricity demand per client Transmission and distribution losses


Electricity demand per client

Item	Unit	2038	Chart
Industry1	%	100.00000	-
Ind1	%	100.00000	✓
Transport	%	100.00000	-
Trn1	%	100.00000	✓
Household	%	100.00000	-
Hou1	%	100.00000	✓
Service	%	100.00000	-
Serv1	%	100.00000	✓

Data notes

©2020, Version: 2.0.0.20201120

Next click on the “Transmission and distribution losses” tab at the top of the page. You can input the transmission and distribution losses for each year of the study in this box. The transmission losses are defined at system level, while the distribution losses are by sectors.



MAED Model for Analysis of Energy Demand

Electricity

Name of the case study **Demo MAEDEL**

Annual electricity demand Electricity supplied from the grid Electricity demand per client **Transmission and distribution losses**

Transmission and distribution losses

Item	Unit	2038	Chart
Transmission losses	%	5.00000	
Distribution losses			
Industry1	%	10.00000	
Transport	%	10.00000	
Household	%	10.00000	
Service	%	10.00000	

Data notes

©2020, Version: 2.0.0.20201120

Next, click on the “Calendar” page under the “General information” tab in the navigation menu on the left side of the page.

First, go to the “Days” box in the upper left. In the top table of this box, you can define the types of days to be modelled. In this demo case, Day type 1 is prefilled with Working days and Day type 2 is prefilled with Saturday-Sunday-Holiday. This means that every day of the year will be modelled as either a working day or a holiday, with no differentiation between weekdays. You can define up to 7 typical days. MAED has 11 typical days predefined: each day of the week separately, grouped working days, weekends, Sundays together with holidays, and any day grouping the 7 weekdays. The option any day can be used when there are no differences in the demand pattern of the days of the week.

At the bottom of this box you can also select the first day of the week from a drop-down menu.

MAED Model for Analysis of Energy Demand

MAED EL About

En Es Fr

Manage case studies

General information

General data

Electricity

Calendar

Coefficients

Industry1 (1)

Transport (1)

Household (1)

Service (1)

Calculate

Results

Calendar

Name of the case study **Demo MAEDEL**

Days

	Day type
Day type1	Working days
Day type2	Saturday-Sunday-Holiday

First day of the week: Monday

Seasons

Season	Season name	Starting date (yyyy-mm-dd)
Season1	Winter	2038-01-01
Season2	Spring	2038-04-01
Season3	Summer	2038-06-01
Season4	Autumn	2038-10-01

Type of day definition

	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday	Holiday
Working days	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Saturday-Sunday-Holiday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Sunday-Holiday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Any day	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

©2020, Version: 2.0.0.20201120

Next, go to the “Seasons” box in the upper right. This box is where you can input the starting date of each season or period, with the format: year, month, day, and name of each season. You can define up to 12 seasons.

MAED Model for Analysis of Energy Demand

MAED EL About

En Es Fr

Manage case studies

General information

- General data
- Electricity
- Calendar

Coefficients

- Industry1 (1)
- Transport (1)
- Household (1)
- Service (1)

Calculate

Results

Calendar

Name of the case study **Demo MAEDEL**

Days

	Day type
Day type1	Working days
Day type2	Saturday-Sunday-Holiday

First day of the week: Monday

Seasons


Season	Season name	Starting date (yyyy-mm-dd)
Season1	Winter	2038-01-01
Season2	Spring	2038-04-01
Season3	Summer	2038-06-01
Season4	Autumn	2038-10-01

Type of day definition

	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday	Holiday
Working days	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Saturday-Sunday-Holiday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Sunday-Holiday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Any day	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

©2020, Version: 2.0.0.20201120

In the box at the bottom of the page named “Type of day definition” you can edit the definitions of typical days. In this box there is a table that shows which days are included in each category. The column on the left shows the names of the typical days that can be selected and in the upper row the days of the week. To change the selection, the days are marked or not according to the desired typical day. If the user wants to make a new selection, they should be careful not to select a day more than once or to omit some of them.



Calendar

Name of the case study: **Demo MAEDEL**

Days

Day type	Day type
Day type1	Working days
Day type2	Saturday-Sunday-Holiday

First day of the week: **Monday**

Type of day definition

	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday	Holiday
Working days	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Saturday-Sunday-Holiday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Sunday-Holiday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Any day	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>


Seasons

Season	Season name	Starting date (yyyy-mm-dd)
Season1	Winter	2038-01-01
Season2	Spring	2038-04-01
Season3	Summer	2038-06-01
Season4	Autumn	2038-10-01

©2020, Version: 2.0.0.20201120

Activity 2: Modulating coefficients

Now click on the first sector in the “Coefficients” tab in the navigation menu on the left. In this demo case, the first sector is “Industry1.” At the top of the page, select the “Weekly coefficients” tab. This table is where you can input the weekly coefficients for each year in the model. You can switch between clients using the dropdown menu in the upper right of the box. However, for this demo case, there is only one client per sector.



MAED Model for Analysis of Energy Demand

MAED EL About

En Es Fr

Manage case studies

General information

Coefficients

Industry1 (1)

Transport (1)

Household (1)

Service (1)

Calculate

Results

Coefficients

Name of the case study Demo MAEDEL

Weekly coefficients Daily coefficients Hourly coefficients

Weekly coefficients

Clients Ind1

Week	2038
1	1.02008
2	1.03358
3	1.05017
4	0.95966
5	1.01626
6	1.00275
7	1.00636
8	0.96744
9	1.00552
10	1.01530
11	0.98370
12	1.02983
13	1.02966
14	0.87465
15	0.94519
16	0.92481
17	0.93293
18	0.94999
19	0.97454
20	0.97499
21	0.98035

©2020, Version: 2.0.0.20201120

Now click on the tab labelled “Daily coefficients” at the top of the page. On this page, you can input the daily coefficients for each week and day of the week in the table. You can select the model year and client in the dropdown menus on the upper right.

MAED Model for Analysis of Energy Demand

MAED EL About

En Es Fr

Manage case studies

General Information

Coefficients

Industry1 (1)

Transport (1)

Household (1)

Service (1)

Calculate

Results

Coefficients

Name of the case study Demo MAEDEL

Weekly coefficients Daily coefficients Hourly coefficients


Daily coefficients

Years 2038 Clients Ind1

Week	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday	Total
1	0.97627	0.99432	1.00683	1.01943	1.00697	1.01990	0.97627	7
2	0.97627	0.99432	1.00683	1.01943	1.00697	1.01990	0.97627	7
3	0.99229	0.99848	0.99398	1.00100	1.00376	1.01820	0.99229	7
4	0.99999	1.10882	1.00457	0.93769	0.96106	0.98789	0.99999	7
5	0.96326	0.99136	0.99531	1.00493	1.04210	1.03977	0.96326	7
6	0.99093	1.00953	0.99423	0.99697	1.00320	1.01420	0.99093	7
7	0.94148	1.03409	1.02809	1.03635	1.00287	1.01565	0.94148	7
8	0.97037	1.01524	1.01822	1.01764	1.05331	0.95486	0.97037	7
9	0.95694	1.02314	1.02511	1.00854	1.00280	1.02653	0.95694	7
10	0.95111	1.00695	1.00734	1.02254	1.04185	1.01909	0.95111	7
11	0.97860	0.98951	0.97158	0.99904	1.03556	1.04710	0.97860	7
12	0.97860	0.98951	0.97158	0.99904	1.03556	1.04710	0.97860	7
13	0.97535	1.00582	1.01244	1.01295	1.00581	1.01228	0.97535	7
14	1.01270	0.98454	0.96546	0.98003	0.99872	1.04586	1.01270	7
15	0.95670	0.99931	0.98262	1.01008	1.05216	1.04243	0.95670	7
16	0.95340	0.97150	1.00192	1.03615	1.04293	1.04070	0.95340	7
17	0.95313	0.97593	1.02188	1.02142	1.03220	1.04230	0.95313	7
18	0.95309	1.02288	1.00635	1.01508	1.01267	1.03683	0.95309	7
19	0.94511	1.00526	1.02815	1.02335	1.03199	1.02103	0.94511	7
20	0.95610	1.00206	1.00833	1.02020	1.02588	1.03134	0.95610	7
21	0.92994	1.02189	1.03625	1.03800	1.03651	1.00747	0.92994	7

©2020, Version: 2.0.0.20201120

Now click on the tab labelled “Hourly coefficients” at the top of the page. In this table, you can input hourly coefficients for each typical day in each of the seasons. Again, you can select the model year and client in the dropdown menus on the upper right.



MAED Model for Analysis of Energy Demand

MAED EL About

En Es Fr

Manage case studies

General information

Coefficients

Industry1 (1)

Transport (1)

Household (1)

Service (1)

Calculate

Results

Coefficients

Name of the case study Demo MAEDEL

Weekly coefficients Daily coefficients Hourly coefficients

Hourly coefficients


Years 2038 Clients Ind1

Hour	Winter		Spring		Summer		Autumn	
	Wd	SSH	Wd	SSH	Wd	SSH	Wd	SSH
0	0.93335	1.00844	1.00916	0.67425	0.93335	1.00844	1.00916	0.67425
1	0.89120	0.95831	0.96339	0.64011	0.89120	0.95831	0.96339	0.64011
2	0.85520	0.92318	0.92315	0.62769	0.85520	0.92318	0.92315	0.62769
3	0.84671	0.92862	0.91410	0.62747	0.84671	0.92862	0.91410	0.62747
4	0.86487	0.95629	0.94459	0.66670	0.86487	0.95629	0.94459	0.66670
5	0.89630	0.96033	0.95680	0.82580	0.89630	0.96033	0.95680	0.82580
6	0.97240	0.98251	0.97157	1.06076	0.97240	0.98251	0.97157	1.06076
7	1.02566	1.02078	0.99410	0.99422	1.02566	1.02078	0.99410	0.99422
8	1.04552	0.99172	0.99307	1.01381	1.04552	0.99172	0.99307	1.01381
9	1.02079	0.99890	0.95780	1.05711	1.02079	0.99890	0.95780	1.05711
10	1.02497	0.99402	0.95447	1.16651	1.02497	0.99402	0.95447	1.16651
11	1.00872	0.98340	0.96559	1.23039	1.00872	0.98340	0.96559	1.23039
12	1.03161	0.99024	0.98276	1.10632	1.03161	0.99024	0.98276	1.10632
13	1.00737	0.99103	0.99602	1.00989	1.00737	0.99103	0.99602	1.00989
14	1.01450	0.99926	1.01651	1.03488	1.01450	0.99926	1.01651	1.03488
15	1.02100	0.99614	1.02270	1.11989	1.02100	0.99614	1.02270	1.11989
16	1.06220	0.98179	1.01213	1.30062	1.06220	0.98179	1.01213	1.30062
17	1.12991	1.04095	1.05307	1.52228	1.12991	1.04095	1.05307	1.52228
18	1.10738	1.05673	1.06970	1.54954	1.10738	1.05673	1.06970	1.54954
19	1.11182	1.06800	1.05230	1.28529	1.11182	1.06800	1.05230	1.28529


©2020, Version: 2.0.0.20201120

Activity 3: Calculate and results


Once all the input data have been defined, MAED-EL can calculate the hourly electricity demand. To do this, click on the “Calculate” tab that is in the navigation menu on the left side of the page. This operation may take a few minutes.



After the calculation is complete, MAED-EL will automatically take you to the “Results” tab in the navigation menu on the left side of the screen. First, click on the “Summary” tab on the top of the page. This shows a table that summarizes your results with key statistics about energy demand, including the annual and by season peak demands, the total electricity demands, the load factors, as well as the difference between the total electricity demand calculated from the coefficients and the one defined by user in the input data. You can use the buttons on the upper right part of the box to export the results to loadsy, the format required by the WASP model, increase and decrease the number of decimal places, and download the data to Excel.



Now click on the “Chart” tab at the top of the page. Here you can see a plot of hourly demand. Charts can be created for each year of the study and you can adjust the portion of the year displayed using the sliders on the bottom mini-graph. Using the buttons on the upper right, you can switch between the annual load curve, the load duration curve, and the normalized load duration curve, as well as downloading the chart as an image.



Now click on the “Hourly load” tab at the top of the page. You may need to expand the table by clicking on the arrow next to the “Year” cell. This will allow you to view the projected hourly demand for each client and sector. You can use the buttons on the upper right to increase or decrease the number of decimal places and export the table to Excel.

MAED
MAED Model for Analysis of Energy Demand
MAED EL
About

En
Es
Fr

Manage case studies

General information
Coefficients
Calculate
Results

Name of the case study Demo MAEDEL

Summary
Chart
Hourly load

Hourly load (MW)

Year
Hour
Industry1
Transport
Household
Service
Total

Year: 2038 (8,760 items)

Year	Hour	Ind1	Total	Tm1	Total	Hou1	Total	Serv1	Total	Total
2038	1	1280.79149...	1280.79149...	1384.82244...	1384.82244...	1280.79149...	1280.79149...	1384.82244...	1384.82244...	5331.22787...
2038	2	1222.95306...	1222.95306...	1322.02276...	1322.02276...	1222.95306...	1222.95306...	1322.02276...	1322.02276...	5089.95165...
2038	3	1173.55920...	1173.55920...	1266.79166...	1266.79166...	1173.55920...	1173.55920...	1266.79166...	1266.79166...	4880.70172...
2038	4	1161.89978...	1161.89978...	1254.37878...	1254.37878...	1161.89978...	1161.89978...	1254.37878...	1254.37878...	4832.55712...
2038	5	1186.81621...	1186.81621...	1296.21724...	1296.21724...	1186.81621...	1186.81621...	1296.21724...	1296.21724...	4966.06692...
2038	6	1229.95151...	1229.95151...	1312.97576...	1312.97576...	1229.95151...	1229.95151...	1312.97576...	1312.97576...	5085.85455...
2038	7	1334.37979...	1334.37979...	1333.24106...	1333.24106...	1334.37979...	1334.37979...	1333.24106...	1333.24106...	5335.24173...
2038	8	1407.46846...	1407.46846...	1364.16067...	1364.16067...	1407.46846...	1407.46846...	1364.16067...	1364.16067...	5543.25828...
2038	9	1434.71521...	1434.71521...	1362.73984...	1362.73984...	1434.71521...	1434.71521...	1362.73984...	1362.73984...	5594.91011...
2038	10	1400.78522...	1400.78522...	1314.34422...	1314.34422...	1400.78522...	1400.78522...	1314.34422...	1314.34422...	5430.25889...
2038	11	1406.52391...	1406.52391...	1309.78234...	1309.78234...	1406.52391...	1406.52391...	1309.78234...	1309.78234...	5432.61250...
2038	12	1384.22541...	1384.22541...	1325.03446...	1325.03446...	1384.22541...	1384.22541...	1325.03446...	1325.03446...	5418.51974...
2038	13	1415.63112...	1415.63112...	1348.59917...	1348.59917...	1415.63112...	1415.63112...	1348.59917...	1348.59917...	5528.46059...
2038	14	1382.36876...	1382.36876...	1366.78942...	1366.78942...	1382.36876...	1382.36876...	1366.78942...	1366.78942...	5498.31637...

©2020. Version: 2.0.0.20201120